

## **Premier Whole House Sediment Filter Installation Instructions**

Professional Installation Recommended

1. Choose an area for installation that will be relatively easy to access to change the filters. Be sure to mount the housing with a minimum of 4" of clearance from the floor to the bottom of the housing. Install the system so that water enters the sediment filter "IN" port of the 10" Big Blue housing.

We also recommend installation of a shut off valve (not included) prior to the inlet of the sediment filter (10" Big Blue Housing).

Optionally, the water may be shut off at your water meter for filter changes. The red "button" on the top of the black housing lid is a pressure relief valve to release water pressure prior to changing the filter.

Use the filter wrench (supplied) and a small amount of Vaseline on the "O" ring and housing threads during initial assembly or when changing the filters.

2. Unscrew the black lid from the housing, then attach the mounting brackets to the housing lid by using the included screws. CAUTION: Note the IN and OUT labeling on the housing lid and mount accordingly. Next, mount the assembled lid and bracket to the wall. Remember to mount at high enough to allow the big blue housing to drop down for filter changes (at least 4" from housing to floor).

3. The mounting process may require several elbows, nipples, reducers, shut off valves and a supply of Teflon tape (we prefer the heavier pink tape) and/or pipe dope, all available at your local hardware or big box store.

4. The sediment filter should be replaced when a noticeable pressure drop in flow is detected.

**If you have any questions, please call 9-5 Central, M-F @ 800-842-4605.**